











































編號	產品名稱	適用產品	價格 (含稅含運費)
UP-01	 <p>WMC (MCE)名片型(小)遙控器 27Key WMC (MCE)遙控器接收器 USB延長線</p>	U2500 (選配)	600
R-01	 <p>銀色遙控器</p>	E650、E700、E800、T750、T300、X800、M800、H900、U1500	300
R-02	 <p>灰色遙控器</p>	M系列: X350、X500、X100、X200、E500、S350、T200、U1350	300
R-03	 <p>名片型遙控器(小) 32key</p>	U900、U890、U150、U2600、X30、X50、E300、S300、S500	250
R-04	 <p>WMC (MCE)名片型(小)遙控器(IR200) 27Key</p>	E300F、U100、U890F、U2800F	300
R-05	 <p>WMC (MCE)名片型(大)遙控器IR250 43Key</p>	M320F、U750F、U180	400
R-06	 <p>IR50 遙控器</p>	U2650	250
R-07	 <p>IR145 WMC (MCE)遙控器</p>	E500F、E600F、E650F、E800F、E850F、E900F、H900F、T750F、T500F、M3F、M5F、M1F、U2850、K100	500
R-08	 <p>黑色遙控器</p>	V300	300
R-09	 <p>白色遙控器</p>	V600、V550	300
R-10	 <p>名片型銀灰遙控器 30key</p>	V200、V220、V140	250
R-11	 <p>名片型銀灰遙控器 32Key</p>	W600、W660、W700	250
R-12	 <p>名片型銀灰遙控器(RYBG)</p>	W800F	250

H-01		短鐵片	T300	80
H-02		短鐵片	H900、X200、M3F、M5F、T500F	80
H-03		短鐵片	X350、X100 (I頭)	80
H-04		短鐵片	DV800、DV850	80
H-05		短鐵片	E300、E500、E650、E800	80
T-01		訊號轉接頭 F(公)->I(母)	適用每種型號	80
T-02		訊號轉接頭 I(公)->F(母)	適用每種型號	80
T-03		電視訊號轉接頭 MCX	U880、U900、U3	80
T-04		訊號轉接頭 F(公)->F(母)	適用每種型號	80
T-05		一轉二分接器	E900F、T750F	150
C-01		自動開機線	適用每種型號	80
C-02		內接式音源線	適用每種型號	100
C-03		外接式音源線	適用每種型號	100
C-04		立體聲音源線 (3.5mm phonejack)	U800、U700、V系列	100

C-05		USB<-->電腦連接線 (方頭)	U800、U700、U600	100
C-06		USB<-->電腦連接線 (扁頭)	U3、U880、U100、U890、U890F、U2650、U2800F、U2850、U系列	100
C-07		USB<-->電腦連接線 (小頭)	U900	100
C-08		USB電源線(大孔)	U800、U700、U600	100
C-09		電源線	U1500、U1350	100
C-10		FM 硬式天線	所有具備FM功能的產品	150
C-11		FM 軟式天線	所有具備FM功能的產品 (PH頭)	100
			U2650、U2800F、U890F (I頭)	100
C-12		Y型-S端子& AV端子線	U800、U700	150
C-13-1		1對4 訊號線	H900、X800、X500、X350	200
C-13-2		1對4訊號線	W600、W660、W700、W800	200
C-14-1		變壓器	U1500、U1350	400
C14-2		12伏1A變壓器	V600	420
C14-3		5伏2A變壓器	V300、V150、V200、W700、W600、W800F、W660	400
C-15		牛角天線	所有DVB-T數位產品	300

C-16		USB延長金屬蛇管	適用每種型號	200
C-17		1對6 訊號線 AV/S/色差	E系列	200
C-18-1		1對3 訊號線 AV/S端子	E系列	180
C-18-2		1對3 Mini USB Cable	U系列	150
C-19		IR 接收器	PCI/ PCIe 電視卡系列	150
C-20		MCX <--> I頭連接線	U3、U2700	200
C-21-1		D-Sub線	V200、V140、W600、W660、W700、W800	150
C-21-2		D-Sub線	V550、V600	150
C-21-3		D-Sub線	V300	150